




Repairing Lexmark Intuition S505 Wireless Connection

This guide will inform readers how to fix any wireless connection problems.


Written By: Raymond



INTRODUCTION

Wireless connection allows users of the printer to connect to the printer without the use of wires.

Step 1 — Wireless Connection



- Turn wireless connection on your computer off and on. Sometimes doing this step is needed to have a connection.
- Check the network to make sure the computer and printer are connected to the same network.

Step 2



- Make sure "Demo Mode" is turned OFF. Locate LED control panel and select "Setup". From there locate "Demo Mode" and turn it off.

Step 3



- Move the printer close to the router to ensure a strong connection.

Once your wireless connection is set up, you should now be able to print documents from your computer without having to use the USB chord.

This document was last generated on 2017-06-18 07:18:04 AM.